



We have an entire line of tools to aid in the safe removal and installation of bearings into all parts of the bicycle. Our tools are 100% US made by Sonny's Bicycle Tools here in California.

We offer a wide variety of tools to cover most bearing applications you may encounter.



BRT-003 BB86/92 Tool



CT-010 Pedal Dummy



CT-008 Hollowgram Tool



BBT-001/B Shimano Tool

Part Number

Model


Description

New Item

Bottom Bracket Tools

BRT-003	BB86/92 Tool	Tool for the removal and install of all BB86 and BB92 systems
CT-010	Pedal Dummy	Drive side only
BBT-001	X-Drive Cup Tool	Tool for removal and install of any FSA, Shimano, SRAM, Truvativ or Enduro style outboard cups
BBT-001/B	Shimano Fixing Bolt Tool	Tool for removal and install of crank fixing bolt
BRT-001	X-Drive BB Tool Set	Tool for removal and install of bearings into any standard outboard cups
BBT-020	Shimano FC24/FC25 Cup Tool	Cup tool for DA 9000/Ult 6800 and XTR/XT
CT-006	Campagnolo Ultra Torque Bearing Removal Tool	Tool for removing the bearing from the crank spindle on Campagnolo cranks
CT-007	Campagnolo Ultra Torque Bearing Install Pilots	These pilots work with the BRT-005 (Hub Press) to press new bearings onto the Ultra Torque cranks
CT-008	Cannondale Hollowgram Crank Removal Tool	This tool allows you to easily remove the Cannondale Hollowgram crank arms without damage
CT-001	Cannondale Crank Spider	This tool allows you to swap out the chain rings on Cannondale cranks by removing the spider

Part Number	Model	Description
New Item		
CT-002	FSA, Cann, Zipp Cap Pin Tool	This tool allows you to remove the cap pin on the FSA, Cannondale and Zipp cranks
CT-003	Rotor 30mm Spider Tool	This tool allows you to remove and replace the lockring for standard or compact spider new style
CT-003/2	Rotor 30mm Mtn Spider Tool	This tool allows you to remove and replace the lockring for the spider on the Rotor mountain 30mm cranks and other fitments
CT-004	Rotor 24mm Spider Tool	This tool allows you to remove and replace the lockring for the spider on the Rotor Rex mountain cranks




CT-003/2 Rotor 30mm Spider Tool



BBT-015 and BBT-025 Pro Cup Tools

Torqtite Cup Tools

TK TorqTite Wrench	TT wrench for BB86/92, PF30	
BBT-015	Torqtite BB86/92/BSA30 pro cup tool	
BBT-025	TorqTite PF30 pro cup tool	



BB30 Tool

BRT-002	BB30 Bottom Bracket Tool	This tool allows you to safely remove and install the 6806 Bearings into any PF30 or BB30 bottom brackets
---------	--------------------------	---

BRT-002 BB30 Tool

BB90 Tool

BBT-006	BB90 Bottom Bracket Tool	This tool works in conjunction with the BBT-005 to press bearings into the BB90 bottom brackets. Will work with Shimano and SRAM style bearings from Enduro
---------	--------------------------	---



BBT-006 BB90 Tool

Part Number

Model

Description

New Item

Hub and Suspension Pivot Tools

BBT-200	Pro Blind Hole Puller Set	This pro tool has the same features as BBT-100. Made of stainless steel, the shaft also unthreads into two pieces for smaller jobs and makes it easier to travel with
BBT-100	Blind Hole Puller Set	This tool set allows you to pull and bearings that are pressed into a housing as found in all hubs and pivots. Work with any bearing with an inside diameter between 8-40mm
BRT-005	Hub Press	Tool set for pressing bearings into hubs, pivots or some BB's. Contains 12 bushing to fit all of the major size bearings used in hubs and pivots



BBT-200 Blind Hole Puller Set

BRT-045	Hub/Needle Bearing Press	Tool for pressing smaller size bearings and needle bearings
LHT-001	Lefty Hub Pin Tool	Pin tool for remove/replace Lefty cap on Cannondale Lefty hubs
BBT-105	V-Type Bearing puller	Small bearing puller tool 8-25 mm
NBT-030	Needle Bearing Tool	Removal/Install tool guides for BRT-005 and BRT-045
BBT-013	Star Ratchet/Seal Driver/ Hub Bearing Guide Tool Set	Star Ratchet tool, seal driver and complete hub bearing guides for DT hubs



BRT-005 Hub Press



BRT-045 Hub/Needle Bearing Press

Small Parts for Tools

TK HT T-Handle	BBT-007	Handle for BRT-005
TK HT Rod	BBT-008	Threaded rod for BRT-005 handle
TK PT 003		Pilot bushing for BRT-001
TK PT 005		Bushing for Truvative
TK PT 006		Split collet for BRT-001
TK PT 007		Support washer/ BRT-001
TK PT 008		Threaded cup/BRT-001
TK PT 009	BRT-003 Collet	Split collet for BB 86/92 tool
TK PT 030	BRT-002 Collet	Split collet for BB30/PF30 tool



NBT-030 Needle Bearing Tool

Part Number

Model

Description

New Item

Inner Hub Pilots and Outer Guides

TK HT 6000 Inner	Guide for 6000 bearing	Inner hub press tool guide
TK HT 6000 Outer	Guide for 6000 bearing	Outer hub press tool guide
TK HT 6001 Inner	Guide for 6001 bearing	Inner hub press tool guide
TK HT 6001 Outer	Guide for 6001 bearing	Outer hub press tool guide
TK HT 608 Inner	Guide for 608 bearing	Inner hub press tool guide
TK HT 608 Outer	Guide for 608 bearing	Outer hub press tool guide
TK HT 6704 Outer	Guide for 6704 bearing	Outer hub press tool guide
TK HT 6800 Inner	Guide for 6800 bearing	Inner hub press tool guide
TK HT 6801 Inner	Guide for 6801 bearing	Inner hub press tool guide
TK HT 6801 Outer	Guide for 6801 bearing	Outer hub press tool guide
TK HT 6802 Inner	Guide for 6802 bearing	Inner hub press tool guide
TK HT 6802 Outer	Guide for 6802 bearing	Outer hub press tool guide
TK HT 6803 Inner	Guide for 6803 bearing	Inner hub press tool guide
TK HT 6803 Outer	Guide for 6803 bearing	Outer hub press tool guide
TK HT 6804 Inner	Guide for 6804 bearing	Inner hub press tool guide
TK HT 6804 Outer	Guide for 6804 bearing	Outer hub press tool guide
TK HT 6805 Inner	Guide for 6805 bearing	Inner hub press tool guide
TK HT 6805 Outer	Guide for 6805 bearing	Outer hub press tool guide
TK HT 6806 Inner	Guide for 6806 bearing	Inner hub press tool guide
TK HT 6900 Inner	Guide for 6900 bearing	Inner hub press tool guide
TK HT 6901 Inner	Guide for 6901 bearing	Inner hub press tool guide
TK HT 6901 Outer	Guide for 6901 bearing	Outer hub press tool guide
TK HT 6902 Inner	Guide for 6902 bearing	Inner hub press tool guide
TK HT 6902 Outer	Guide for 6902 bearing	Outer hub press tool guide
TK HT 6903 Inner	Guide for 6903 bearing	Inner hub press tool guide
TK HT 6903 Outer	Guide for 6903 bearing	Outer hub press tool guide
TK HT MR 1526 Inner	Guide for 1526 bearing	Inner hub press tool guide
TK HT MR 1526 Outer	Guide for 1526 bearing	Outer hub press tool guide



BBT-013 DT Hub Toolset



TK puller 8-10mm Blind Puller

Part Number

Model

Description

New Item

TK HT MR 1728 Inner	Guide for 1728 bearing	Inner hub press tool guide
TK HT MR 1728 Outer	Guide for 1728 bearing	Outer hub press tool guide
TK HT MR 18307 Inner	Guide for 18307 bearing	Inner hub press tool guide
TK HT MR 18307 Outer	Guide for 18307 bearing	Outer hub press tool guide
TK HT R6 Inner	Guide for R6 bearing	Inner hub press tool guide
TK HT R6 Outer	Guide for R6 bearing	Outer hub press tool guide
TK HT MR 2437 Inner	Guide for 2437 bearing	Installs both 6805 and MR 2437 bearings
TK HT Multi-Inner	BBT-005	All Inner Guides
TK HT Multi-Outer	BBT-004	All Outer Guides

Replacement Blind Puller

TK puller 8-10mm		Individual replacement puller for 8-10 mm
TK puller 10-12mm		Individual replacement puller for 10-12 mm
TK puller 12-14mm		Individual replacement puller for 12-24 mm
TK puller 15-17mm		Individual replacement puller for 15-17 mm
TK puller 20-24mm		Individual replacement puller for 20-24 mm
TK puller 25-29mm		Individual replacement puller for 25-29 mm
TK puller 30-32mm		Individual replacement puller for 30-32 mm