

# Misc BB parts

## Seals

<u>Part number</u>	<u>Frame</u>	<u>Cranks</u>
SE MR 2237	BB 86 or 92	Non drive Sram
SE MR 2241	Outboard Cups	Non drive Sram
SE MR 2437	BB 86 or 92	Shimano
SE MR 2441	Outboard Cups	Shimano
SE MR 3042	BB30	BB30
END. 281820	BB90	Shimano

## Spacers

### Part Number

WA 24x0.5	spacer
WA 24x1.0	spacer
WA 30x0.5	spacer
WA 30x1.0	spacer
WA Wave 24	24mm wave washer
WA Wave 30	30mm wave washer
WA 22x24x11.5 F	Sram Adaptor
WA 25.4x29x0.5 NY	Retainer clip for XD-15
WA 31.5x35x0.5 NY	Retainer clip for BB30 XD-15

## Snap Rings

RR Ring IN 44 SS	Snap rings for BB30
------------------	---------------------

## Parts for Tools

TK HT T-Handle	Replacment handle for BRT-005
TK PT 003	Pilot Bushing for BRT-001
TK PT 005	Bushing Truvative
TK PT 006	Split Collet for BRT-001
TK PT 007	Support washer/ BRT-001
TK PT 008	Threaded Cup/BRT-001
TK HT 6000	Guide for 6000 bearing
TK HT 6001	Guide for 6001 bearing
TK HT 608	Guide for 608 bearing
TK HT 6802	Guide for 6802 bearing

TK HT 6803	Guide for 6803 bearing
TK HT 6804	Guide for 6804 bearing
TK PT 6805	Guide for 6804 bearing
TK PT 6901	Guide for 6901 bearing
TK PT 6902	Guide for 6902 bearing
TK PT 6903	Guide for 6903 bearing
TK PT MR 1526	Guide for 1526 bearing
TK PT R6	Guide for R6 bearing

TK puller 8-10mm  
TK puller 10-12mm  
TK puller 12-24mm  
TK puller 15-17mm  
TK puller 20-24mm  
TK puller 25-29mm  
TK puller 30-32mm